


BASE PIN SENSOR ASSEMBLY



No	Code	Description	Qty
1	SS1-FP-032-R1	BA-Floor	1
2	SS1-FW-013-R1	Pin base lower	1
3	SS1-FW-014-R0	Pin base spacer	1
4	SS1-FM-069-R0	Pin base bracket	1
5	-	Sensor Pin	10

