




TIME BUSTER



NO	PART NO	DESCRIPTION	QTY	
01	TB1 A001	FRONT DOOR ASSEMBLY	1	
SUB ASSY	01A	TB1-SA-23-RO	DOOR FRAME METAL ONLY	1
	01B	TB1 A001A	TRIPLE LOCK ASSEMBLY	1
	01C	HM0004	EAGLE LOCK	1
	01D	TB1-FM-34-RO	TRIPLE LOCK COVER	1
	01E	TB1-FG-01-RO	FRONT GLASS DOOR	1
	01F	TB1-FM-16-RO	FRONT GLASS LOWER&UPPER CLAMP	2
	01G	TB1-FM-32-RO	FRONT GLASS LEFT&RIGHT CLAMP	2
-	AT3212	STICKER PLAY INSTRUCTION	1	
02	TB1 A008A	COINDOOR 1DBA 1COIN MECHANIC ASSY	1	
PART ITEM	02A	HM0004	EAGLE LOCK	1
	02B	TB1-FM-53-RO	THANDLE COVER	1
	02C	TB1-SA-11-RO	COINDOOR METAL ONLY 1DBA 1COIN MECHANIC	1
	02D	-	DOLLAR BILL ACCEPTOR	1
	02E	HM0014	COIN MECHANISM	1
	02F	EA0520	SWITCH SMALL ROUND GREEN BUTTON	1
	02G	EA0519	SWITCH SMALL ROUND RED BUTTON	1
-	TB1 H002A	HARNES COINDOOR 1DBA 1COIN MECHANIC	1	
03	TB1 A008B	COINDOOR 2 COIN MECHANIC ASSY	1	
PART ITEM	03A	HM0004	EAGLE LOCK	1
	03B	TB1-FM-53-RO	THANDLE COVER	1
	03C	TB1-SA-11-RO	COINDOOR METAL ONLY 2 COIN MECHANIC	1
	03D	HM0014	COIN MECHANISM	2
	03E	EA0520	SWITCH SMALL ROUND GREEN BUTTON	1
	03F	EA0519	SWITCH SMALL ROUND RED BUTTON	1
	-	TB1 H002B	HARNES COINDOOR 2 COIN MECHANIC	1