



FRONT TRACK ASSEMBLY



No	Code	Description	Qty	
1	SSI-FW-051-R1	FT-Outside right	1	
2	SSI-FW-052-R1	FT-Outside left	1	
3	SSI-FW-053-R0	FT-Inside right	1	
4	SSI-FW-054-R0	FT-Inside left	1	
5	SSI-FW-055-R0	FT-Base	1	
6	SSI-FW-056-R0	FT-Support 1	1	
7	SSI-FW-057-R0	FT-Support 2	2 (R+L)	
8	SSI-FW-058-R0	FT-Support 3	1	
9	SSI-FW-059-R0	FT-Support 4	3	
10	SSI-FW-060-R0	FT-Support 5	2	
11	SSI-FW-061-R0	FT-Support 6	1	
12	SSI-FW-062-R0	FT-Support 7	1	
13	-	PE Tape 1"	2	
14	SSI-FW-064-R0	FT-Support 9	2 (R+L)	
15	SSI-FW-065-R0	FT-Lower base	1	
16	SSI-FW-066-R0	FT-Door	1	
17	SSI-FP-018-R0	Front track right 1	1	
18	SSI-FP-019-R0	Front track left	1	
19	SSI-FP-037-R0	Front track right 2	1	
20	SSI-FP-012-R0	Slide cash box	1	
21	SSI-FP-027-R0	Ball stopper 1	3	
22	SSI-FP-038-R0	Ball stopper 2	2 (R+L)	
23	SSI-FP-029-R0	FT-Floor	1	
24	SSI-SA-017-R0	Chash box set	1	
25	SSI-SA-008-R1	FT-Cash door subassy	1	
26	SSI-FM-036-R0	FT-Door base flaten	2	
27	SSI-SA-015-R0	FT-Frame DBA subassy	1	
28	SSI-FM-031-R0	FT-Ticket holder	1	
29	SSI-FM-035-R0	FT-Ticket door	1	
30	SSI-FM-006-R0	Ticket door bracket	1	
31	SSI-FM-040-R0	Bracket track front portion	1	
32	SSI-FM-055-R0	Plate spacer lock	1	
33	SSI-FM-070-R0	Grill speaker	2	
34	SSI-M-007-R0	Hinge FT-Door	2	
35	SSI-M-005-R0	Hinge cash door	1	
36	SSI-M-006-R0	Hinge ticket door	1	
37	-	Rofo lock type standard-Receptacle (R2-0002-02)	2	
38	-	Bracket service	1	
	38A	-	Counter Ticket	1
	38B	-	Coin 1 dan 2	1
	38C	-	Potensio	1
38	-	Bracket Switch service 1	1	
	38A	-	Button Service	1
	38B	-	Button Test	1
	38C	-	Button Up	1
	38D	-	Button Down	1