



NO	PART NUMBER	DESCRIPTION	QTY	
01	SG1-SA-005-R3	Front door SA	1 Set	
02	SG1-Assy-026-R0	Coin & DBA assy	1 Set	
ITEM	02a	SG1-FM-031-R0	Coin & DBA beacket	1 Pcs
	02b	HM0014	Coin mechanism	1 Pcs
	02c	SG1-FM-054-R0	DBA cover	1 Pcs
03	SG1-FG-001-R0	Front door glass	1 Pcs	
04	SG1-FM-045-R1	Front glass clamp 2	2 Pcs	
05	SG1-FM-044-R0	Front glass clamp 1	2 Pcs	
06	SG1-Assy-027-R0	Lock cam cover assy	1 Set	
ITEM	06a	SG1-FM-035-R2	Lock cam cover	3 Pcs
	06b	EA0520	Switch Small Round Green Button P/N: HS-02 M5	1 Pcs
	06c	EA0519	Switch Small Round Red Button P/N: HS-02 M5	1 Pcs
07	SG1-Assy-028-R0	Front door lock assy	1 Set	
ITEM	07a	SG1-FM-021-R0	Lock cam 2	1 Pcs
	07b	SG1-FM-042-R1	Upper rod key	1 Pcs
	07c	SG1-FM-043-R0	Lower rod key	1 Pcs
	07d	Rivet nut M5	Spacer	2 Pcs
08	SG1-FM-047-R0	Front panel bracket	1 Pcs	
09	SG1-Assy-029-R0	Control panel aassy	1 Pcs	
ITEM	09a	SG1-FP-008-R1	Control panel	1 Pcs
	09b	SG1-FM-041-R2	Conrtol panel bracket	2 Pcs
	09c	SG1-FM-037-R1	Speaket cover	1 Pcs
	09d	SG1-FP-014-R2	Joystick base	1 Pcs
	09e	EA 1206	Speaker 4"	2 Pcs
	09f	EA 0591 A	Joystick	1 Pcs
	09g	EA 0523 B	Red button big	1 Pcs
	09h	SG1-FM-073-R1	Joystick support	1 Pcs
10	SG1-FM-012-R5	Front panel clamp SA	1 Set	
11	SG1-FM-34-R1	Front door cover	1 Pcs	
12	SG1-FM-55-R0	Connector bracket	1 Pcs	
13	SG1-Assy-30-R0	Prize door base assy	1 Set	
ITEM	13a	SG1-SA-007-R1	Prize door base SA	1 Set
	13b	SG1-FM-046-R0	Prize door guide 2	1 Pcs
	13c	SG1-SA-006-R1	Prize door SA	1 Set
	13d	SG1-FP-007-R1	Prize door	1 Pcs
	13e	EP 0636	Bushing Ø6	2 Pcs
14	SG1-M-001-R2	Front door hinge	1 Pcs	