


05. BALLGATE ASSEMBLY



| NO | PART NO | DESCRIPTION | QTY | |
|-----------|-----------------|--------------------------|------------------------------------|---|
| 05 | SNJ A014 | BALLGATE ASSEMBLY | 1 | |
| SUB ASSY | 05A | SNJ-SA-08-RO | BALLGATE SHROUD METAL ONLY | 1 |
| | 05B | SNJ A014a | MOTOR BRACKET ASSEMBLY | 1 |
| | - | EA1158 | MOTOR 8000DC MODEL 12VDC 10-16 RPM | 1 |
| | - | SNJ-FM-10-RO | MICROSWITCH BRACKET | 1 |
| | - | EAO405 | SWITCH MICRO ROLLER 50gr VM05506DO | 2 |
| | - | SNJ-FM-48-RO | MOTOR CRANK | 1 |
| | - | HA1427 | TIE ROD END M6 | 2 |
| | - | SNJ-SA-45-RO | MOTOR BRACKET METAL ONLY | 1 |
| | 05C | SNJ-FM-07-RO | BALLGATE CROSS MEMBER | 1 |
| | 05D | SNJ-FM-23-RO | GATE BLOCK | 2 |
| | 05E | SNJ A014b | BALLGATE FLAP ASSEMBLY | 1 |
| - | SNJ-SA-50-RO | BALLGATE FLAP METAL ONLY | 1 | |
| - | SNJ-FM-49-RO | METAL FIXER | 2 | |
| - | SNJ-FP-03-RO | RUBBER GATE | 1 | |
| - | SNJ H008 | BALLGATE HARNESS | 1 | |